## Delta6.4 Keypad Technology Reference Document Delta<sub>6.4</sub>

Multi-Technology Contactless Smartcard Reader and Keypad

The Delta6.4 Multi-Technology Contactless Smartcard Reader and Keypad may be mounted directly to a US-sized singlegang wall box or a flat surface. It is ideal for high security dual verification applications requiring an access credential and/ or personal identification number (PIN). It can also be used as a keypad only.

The proximity reader and keypad portions of the single-piece Delta6.4 both share the Wiegand data lines. Specifically keypad data is transmitted in either an 8-Bit Burst (default) or 26-Bit Wiegand data format. In another Farpointe Data first, the keypad itself is based upon cutting-edge, non-mechanical, capacitive technology, which, unlike membrane keypads, includes no moving parts prone to early failure. Advanced keypad enhancements include backlighting, physical tactile feedback, and a raised pip on the 5-key.

### Please Note:

- The non-mechanical capacitive technology utilized by the Delta6.4 is optimized for use with a bare finger.
- For best operation when entering a PIN it is recommended that the user's finger be physically lifted from the keypad between key depressions. Only one key can be pressed at a time.
- For user orientation in non-illuminated environments the 5-key is always illuminated.
- Card presentation or a key press illuminates the keypad for approximately 20 seconds. Further, each key press generates a single beep and LED flash from the Delta6.4.

#### **Delta6.4 Keypad Output Formats** 1.0

- 8-Bit Burst (factory default setting)
- 26-Bit Wiegand

The factory default Wiegand data transmission setting for the keypad portion of the Delta6.4 is 8-bit burst, though it is capable of transmitting data in 26-Bit Wiegand mode. The keypad uses the Wiegand Keypad Data Mode control card, presented to the reader, to change between 8-bit burst and 26-bit Wiegand data modes.

#### 2.0 **Delta6.4 Keypad Operation: 8-Bit Burst Output**

While in 8-Bit Burst mode each key press results in the Delta6.4 transmitting 8-bits of data to the host according to the Table on page 2.

NOTE: To return the Delta6.4 to the 8-Bit Burst mode of operation:

- 1. Cycle power to the reader, and then verify the reader is powered on.
- Present the Wiegand Keypad Data Mode control card to the reader. The reader beeps four times.
- 3. Press the #-key. The reader beeps four times to indicate programming mode has ended.

#### Delta6.4 Keypad Operation: 26-Bit Wiegand Output 3.0

While in the 26-Bit Wiegand mode the user's PIN is output by the Delta6.4 as the ID Number portion of a 26-Bit Wiegand message. As such PINs can range from 0 to 65534, with 65535 normally reserved as an error code. The facility code is programmed into the reader at set-up, while parity is calculated by the reader. The data comprising the 26-Bit Wiegand message is transmitted to the host only when the #-key is pressed according to the Table on page 2.

NOTE: To verify the keypad's data mode press the star key. If the reader beeps 4-times it is in 26-bit mode, if it beeps 1-time it is in 8-bit burst.

2177 Leghorn Street Mountain View, CA 94043 USA Tel: +1-650-964-2615 Fax: +1-650-988-6687

Email: info@pyramidseries.com Web: www.farpointedata.com



## Delta6.4 Keypad Technology Reference Document

# Delta6.4

Multi-Technology Contactless Smartcard Reader and Keypad

PIN 65535 is normally used as an error code. The Delta6.4 will transmit this code to the host when:

- The #-key is pressed without any preceding digits.
- The 0-key is pressed any number of times before pressing the #-key.
- Entering the PIN 65535, or any PIN greater than 65535.

NOTE: To set-up the Delta6.4 in 26-Bit Wiegand mode of operation:

- 1. Cycle power to the reader, and then verify the reader is powered on.
- Present the Wiegand Data Mode control card to the reader. The reader beeps four times and then enters Facility code programming mode.
- 3. Enter the Facility code to be applied to the keypad. The facility code may be set anywhere from 0 and 255 (one long beep is sounded if a facility code greater than 255 is entered).
- 4. Press the "#" key to exit programming mode. The reader beeps four times to indicate programming mode has ended.

NOTE: Below is a list of important facts regarding the Delta6.4's operation in the 26-Bit Wiegand mode:

- The #-key must be pressed to transmit the 26-Bit Wiegand message to the host.
- Pressing the \*-key overwrites all previous key presses. The reader beeps four times when the \*-key is pressed.
- There is a five second time-out between PIN entries, or entry attempts. If a time-out occurs all previous key presses are overwritten. The reader beeps four times to indicate a time-out has occurred.

8-bit Burst Format Table		
Keypad Entry	Binary Data	Decimal Equivalent
0	11110000	240
1	11100001	225
2	11010010	210
3	11000011	195
4	10110100	180
5	10100101	165
6	10010110	150
7	10000111	135
8	01111000	120
9	01101001	105
*	01011010	90
#	01001011	75

26-bit Wiegand Format Table		
Bit Number	Purpose	
1	Even parity over bits 2 to 13	
2 to 9	Facility Code (0 to 255); Bit 2 is MSB	
10 to 25	ID Number/PIN (0 to 65,535); Bit 10 is MSB	
26	Odd parity over bits 14 to 25	

2177 Leghorn Street Mountain View, CA 94043 USA

Tel: +1-650-964-2615 Fax: +1-650-988-6687

Email: info@pyramidseries.com Web: www.farpointedata.com

