

ENVIROALERT®



Wireless Temperature Accessory for EnviroAlert EA800-ip

- Wireless Temperature Sensor, monitors ambient room temperature
- Transmission distance of 45' to 100' indoor (results may vary).
- Set temperature high/low set points on EnviroAlert console.
- Do **NOT** put EA-WTS in freezer/cooler. Use wired sensor.

Specifications

Sensing Range	32° to 122° F (0° to 50° C)
Power Requirements	2 - AA Alkaline Batteries or +12 VDC @ <=100mA
Battery Life	Alkaline up to 1 year (not included)
Unit Operating Range	32° to 122° F (0° to 50° C) Non-condensing environment.
Frequency	2.405 GHz - 2.480 GHz, 16 channels. See owner's manual for more information.
Transmission Distance	45' to 100' indoor (results may vary)
Weight	0.25 lb (0.11 kg)
Dimensions	3.67 x 2.65 x 1.17" (9.3 x 6.7 x 2.9 cm)
Mounting	Surface Mount

Accessory for
EnviroAlert EA800-ip

Visit www.winland.com, call 800.635.4269 or email techsupport@winland.com to learn more.

